


Instruction manual

VWR® Real-Time Electrophoresis System

North American Catalog Number: 76359-756

European Catalogue Number: 700-1473

European version includes plugs for Europe and UK



This product is for research use only

Legal Address of Manufacturer:

Europe

VWR International bv,
Researchpark Haasrode 2020
Geldenaaksebaan 464 B-3001 Leuven
+3216385011

be.vwr.com

UK Importer:
VWR International Ltd
Hunter Boulevard, Magna Park
Lutterworth, Leicestershire, LE17 4XN

uk.vwr.com

United States

VWR International LLC
100 Matsonford Rd
Radnor, PA 19087
+1 800-932-5000

www.vwr.com

Country of origin: China

Contents

| | |
|--|-----------|
| 1. Introduction..... | 2 |
| 1.1 Included Component List..... | 3 |
| 1.2 Diagrams of Included Components..... | 4 |
| 1.3 Specifications..... | 6 |
| 2. Installation..... | 6 |
| 2.1 Intended Use | 6 |
| 3. Warnings..... | 7 |
| 4. Gel Preparation..... | 8 |
| 5. Gel Tank Set Up | 10 |
| 6. Power Supply Operation / Electrophoresis | 12 |
| 7. Viewing Electrophoresis Progress..... | 13 |
| 8. Imaging using a smart phone..... | 13 |
| 9. Maintenance..... | 14 |
| 10. Troubleshooting..... | 14 |
| 11. Equipment Disposal | 15 |
| 12. Technical Service and Warranty | 16 |
| 13. Addresses and Contacts | 17 |

1. Introduction

Thank you for purchasing the VWR Real-Time Electrophoresis System.

This operating manual includes a product introduction, operating and safety information. Before using the Real-Time Electrophoresis System, please read this manual in its entirety and be sure to fully understand the features and methods for proper operation. Keep this manual for future reference.

Please check the list of included components in section 1.1, and if there are any parts missing, damaged, or incorrect, please contact your distributor or VWR's Customer Service Department. See contact information pg 17.

The Real-Time Electrophoresis System is a complete horizontal electrophoresis system that includes a power supply, gel running tank, safety lid with viewing filter, blue LED transilluminator, and a gel casting set. The system is designed for separating nucleic acids in agarose gels and allows viewing the stained DNA bands during electrophoresis without removing the gel from the tank. All components and accessories are included for casting and running agarose gels. The blue LED transilluminator and viewing filter are compatible with green fluorescent stains such as VWR's EZ Vision Products, SYBR® Green, and other similar stains that fluoresce under 465nm blue light.




Before use, please read this operating manual in its entirety.


1.1 Included Components

| | |
|--|-------|
| Power Supply | 1pc |
| Gel Running Tank Assembly | 1 pc |
| Blue Light LED Illuminator | 1 pc |
| 12VDC Power Supply (for LED Illuminator) | 1 pc |
| Power cord for 115V/230V outlet | 1 pc |
| Gel Casting Stand | 1 pc |
| Gel Casting Divider | 1 pc |
| Long Gel Tray (10.5 x 10cm) | 1 pcs |
| Short Gel Tray (10.5 x 6cm) | 2 pcs |
| Double Sided Comb (12/22 teeth) | 2 pcs |
| AC transformer (only included with 230V model) | 1 pc |
| User Manual | 1 pc |


1.2 Diagrams of Included Components



Smart phone imaging enclosure with photo filter



Safety Lid with Integral Viewing Filter




Gel Running Tank



Power Supply



Transformer and Plugs




Blue LED Transilluminator





12V Power Adapter


Diagram of Included Components (Gel Casting Set)




Double Sided Comb (12/22 teeth)




Short Gel Trays (10.5 x 6cm)



Long Gel Tray (10.5 x 10cm)



Gel Casting Divider



Gel Casting Stand

1.3 Product Specifications

| Power Supply | |
|----------------------------------|--|
| Input voltage | 230V 50/60Hz (Transformer included with 230V input model) |
| Output voltage | 35V, 50V, 100V |
| Max power | 40 Watt |
| Timer | 0 ~ 99min |
| Fuse | 250V, 2A |
| Migration Tank | |
| Dimension | 120mm×110mm×45mm (inner dimension) |
| Buffer volume | 200ml-225ml |
| Electrodes | Platinum wire |
| Blue LED Transilluminator | |
| Viewing area dimension | 10.5cm x 10.5cm |
| Wavelength | 465nm |
| Input voltage | 12VDC (Power Adapter included for 100VAC to 240VAC input) |
| Gel Casting Set | |
| Gel casting stand | Accommodates 10.5cm x 11cm and 10.5cm×6cm trays (Divider included) |
| Comb specifications | Teeth width x Teeth thickness x Teeth no.) 3mm×1mm×22 5.6mm×1mm×12 |
| Gel trays | 10.5cm x 11cm and 10.5cm×6cm |

2. Installation

Place the electrophoresis system on a smooth, level surface.

Connect one end of the power cord to the instrument and the other end to an appropriate outlet, the input voltage should be between 100~120VAC. When the input voltage is 220VAC, use the transformer inline.

2.1. Intended Use

This electrophoresis system is designed for use in a research laboratory for the application of separating nucleic acid molecules in agarose gels.

3. Warnings

Symbols and Conventions

| | |
|---|---|
|  | CAUTION This symbol indicates a potential risk and alerts you to proceed with caution |
|  | CAUTION This symbol indicates the presence of high voltage and warns the user to proceed with caution |



To avoid electrical shock, do not use this product with wet hands.



When operating, do not move or bump the system, do not put your finger or any other objects into the migration tank.



Do not detach the power supply module from the migration tank when the power is on. Attempting to do so can cause damage.



Please carefully read this instruction manual before operation to avoid any personal injury. Only trained laboratory personnel should operate the system.



Do not attempt to open or repair Real-Time Electrophoresis System . Contact VWR for service.



Always use the Real-Time Electrophoresis System in an environment with low humidity and low dust, also keep away from water, direct sunlight / strong light, corrosive gas, high magnetic fields, heaters, fires and other heat sources.



The power switch for the power supply is located on the top of the control panel, press “I” to power on, “O” to turn off.



Always turn off the power after operation. When not in use, detach the power supply and store in an area that is free from moisture and dust.

4. Gel Preparation





Place the gel casting stand on a level surface and place the divider and desired gel trays into the proper positions in the stand.

Either one long gel tray, or two short trays can be inserted into the casting stand (see diagrams on right)


Note: If the gel tray is not level, the thickness of the gel will not be uniform and DNA migration may be uneven.

Insert the comb(s) into the gel casting stand as per photo on the right. Multiple combs can be inserted depending on the number of samples and desired run distance.

Note: when using the fine-toothed comb, the flat side of the well comb should be facing the direction of DNA travel. See figure below.




Pour the agarose gel/DNA stain solution into the gel tray to make a gel approximately 4mm thick. Each 6x10.5cm tray requires about 25ml of agarose.




Note: After mixing and heating agarose solution, let it cool to approximately 60° C before pouring into the gel trays

After the gel has solidified (approximately 20 minutes) hold the two sides of comb and gently lift it out of the gel. The wells should be straight and undamaged.




Carefully remove the gel tray with the gel from the stand and place it into the migration tank in the correct orientation. (DNA samples will migrate from the – to + electrode).



5. Gel Tank Set Up


Note: Make sure that the Real-Time Electrophoresis System is installed on a stable and level surface. This will ensure even sample migration.

Place a prepared gel, together with the gel tray onto the gel bed inside the gel tank.




Carefully pour an appropriate buffer solution to a level about 2 mm above the surface of the gel. Typically, 200ml of buffer is required.

It is recommended to use TAE or TBE at a concentration of 0.5X.




Connect the power supply to the migration tank.




Add DNA samples to the gel

Use an appropriate pipette to carefully dispense samples into the wells of the gel.


Note: Loading buffer should be mixed with the DNA samples so they will sink to the bottom of the wells.



Carefully lower the safety cover onto the gel tank, making sure to align the magnet with the sensor recess. The orange viewing filter should fully contact the surface of the buffer so there are no bubbles visible. If the buffer level is too low, remove the cover, and add more buffer to the tank.




Slide the blue LED illuminator under the gel tank..



6. Power Supply Operation / Electrophoresis

Connect the power cord to the power supply and plug into the appropriate wall outlet.




Connect the 12V power supply to the LED transilluminator

Press ▲ ▼ to set the run time from 1 to 99 min. For a continuous run, set the timer to “00”.

Press the Voltage Selector button to toggle through and select the appropriate output voltage. The LED for the selected voltage will light.

Press the “Start/Stop” button once to start a run. The set output voltage LED will blink to indicate a run is in process. At the end of a timed run, the alarm will beep 3 times, and the display will show “Ed” to indicate END. Press any key to clear “Ed” and set up another run.



To stop a run in process, press and hold “Start/Stop” for 3 second. The voltage LED will stop blinking to indicate the run has stopped.


If removing the gel the end of an electrophoresis run, turn off the power remove the lid and remove the gel tray.

7. Viewing Electrophoresis Progress

To visualize the DNA separation in the gel during electrophoresis, turn on the blue LED illuminator using the ON/OFF switch.

It may be necessary to dim or turn off ambient lights for best viewing results.

The LED illuminator has a built-in timer, so the light will automatically switch off after 5 minutes.




8. Imaging using a smart phone

To take a picture of the gel using a smart phone camera, fit the imaging enclosure onto the lid of the gel running tank.

Insert the included orange photo filter into the top platform of the enclosure. Turn on the smart phone's camera application and align the camera lens with the photo filter.

Zoom and focus as necessary to optimize the image and take the picture.



9. Maintenance



Always disconnect the power cords for cleaning. When cleaning the surfaces of the instrument and LED transilluminator, use a damp cloth with mild detergent if needed. Do not use any corrosive solutions that could damage plastic.



When cleaning the gel tank, first separate the Power Supply. Use water or neutral cleaner.

Use caution when cleaning the areas near the platinum electrodes at the bottom edges of the gel tank.



Do not submerge the power supply or LED transilluminator in water.



Clean gel casting stands, gel tray and combs with water or a neutral cleaner.

10. Troubleshooting

| Problem | Causes | Resolutions |
|------------------------------------|--|---|
| No display | Power not connected. Switch failure. Fuse blown. Controller failure. | Check power supply, Unplug and re-attach power cord. Check fuse. Contact VWR for repair. |
| No Migration | Power switch off, no power, gel inserted backwards | Turn on power switch. Check that gel is properly oriented (DNA will migrate towards + electrode) Contact VWR for repair. |
| Abnormal Electrophoresis Distance | Incorrect input voltage | Check main power supply. |
| Abnormal heating of buffer or gels | Buffer concentration too high, voltage too high | Use 0.5X TAE/TBE buffer or reduce running voltage. |
| Key function failure | Control panel switch failure | Contact VWR for repair. |

Troubleshooting (continued)

| Problem | Causes | Resolutions |
|----------|---|--|
| Error E1 | Lid opened during run or magnet switch problem. | Seat lid properly. Check magnet on lid.. |
| Error E3 | Lid not closed upon start or magnetic switch problem. | Seat lid properly. Check magnet on lid. |
| Error E5 | Electric current not flowing normally. Buffer missing, or concentration too high. | Check proper buffer level in the tank. Check buffer concentration (1X or 0.5X TAE or TBE is standard). Check electrodes and connections. |
| Error E7 | Buffer concentration too high, current too high, power over 50W, or internal electronic problem | Check buffer concentration. Replace electronic board. |

11. Equipment disposal



This equipment is marked with the crossed out wheeled bin symbol to indicate that this equipment must not be disposed of with unsorted waste.

Instead it's your responsibility to correctly dispose of your equipment at lifecycle -end by handling it over to an authorized facility for separate collection and recycling. It's also your responsibility to decontaminate the equipment in case of biological, chemical and/or radiological contamination, so as to protect from health hazards the persons involved in the disposal and recycling of the equipment.

For more information about where you can drop off your waste of equipment, please contact your local dealer from whom you originally purchased this equipment.

By doing so, you will help to conserve natural and environmental resources and you will ensure that your equipment is recycled in a manner that protects human health. Thank you

12. Technical Service and Warranty

Web Resources

Visit the VWR website at www.vwr.com for:

- Complete technical service contact information
- Access to the VWR Online Catalogue, and information about accessories and related products
- Additional product information and special offers

Contact us For information or technical assistance contact your local VWR representative or visit. www.vwr.com.

Warranty

VWR warrants that this product will be free from defects in material and workmanship for a period of two (2) years from date of delivery. If a defect is present, VWR will, at its option and cost, repair, replace, or refund the purchase price of this product to the customer, provided it is returned during the warranty period. This warranty does not apply if the product has been damaged by accident, abuse, misuse, or misapplication, or from ordinary wear and tear. If the required maintenance and inspection services are not performed according to the manuals and any local regulations, such warranty turns invalid, except to the extent, the defect of the product is not due to such non-performance.

Items being returned must be insured by the customer against possible damage or loss. This warranty shall be limited to the aforementioned remedies. IT IS EXPRESSLY AGREED THAT THIS WARRANTY WILL BE IN LIEU OF ALL WARRANTIES OF FITNESS AND IN LIEU OF THE WARRANTY OF MERCHANTABILITY.

Compliance with local laws and regulations. The customer is responsible for applying for and obtaining the necessary regulatory approvals or other authorisations necessary to run or use the Product in its local environment. VWR will not be held liable for any related omission or for not obtaining the required approval or authorisation, unless any refusal is due to a defect of the product.

Our local offices in Europe, AMEA and North America

Austria

VWR International GmbH
Graumanngasse 7
1150 Vienna
Tel.: +43 1 97 002 0
Email: info.at@vwr.com

Belgium

VWR International BV
Researchpark Haasrode 2020
Geldenaaksebaan 464
3001 Leuven
Tel.: +32 016 385 011
Email: vwr.be@vwr.com

Canada

VWR International
2360 Argentia Road
Mississauga, Ontario L5N 5Z7
Tel.: +1 800 932 5000
Email: Canada_Orders@vwr.com

China

VWR (Shanghai) Co., Ltd
Bld.No.1, No.3728 Jinke Rd,
Pudong New District
Shanghai, 201203- China
Tel.: +400 821 8006
Email: info_china@vwr.com

Czech Republic

VWR International s. r. o.
Veetee Business Park
Pražská 442
CZ - 281 67 Strižná Skalice
Tel.: +420 321 570 321
Email: info.cz@vwr.com

Denmark

VWR International A/S
Tobaksvejen 21
2860 Søborg
Tel.: +45 43 86 87 88
Email: info.dk@vwr.com

Finland

VWR International Oy
Valimotie 17-19
00380 Helsinki
Tel.: +358 9 80 45 51
Email: info.fi@vwr.com

France

VWR International S.A.S.
Immeuble Estréo
1-3 rue d'Aurion
93114 Rosny-sous-Bois cedex
Tel.: 0 825 02 30 30* (national)
Tel.: +33 (0) 1 45 14 85 00 (international)
Email: info.fr@vwr.com
* 0,18 € TTC/ min + prix appel

Germany

VWR International GmbH
Hilpertstrasse 20a
D - 64295 Darmstadt
Freecall: 0800 702 00 07
Tel.: +49 (0) 6151 3972 0 (international)
Email: info.de@vwr.com

Hungary

VWR International Kft.
Simon László u. 4.
4034 Debrecen
Tel.: +36 (52) 521-130
Email: info.hu@vwr.com

India

VWR Lab Products Private Limited
No.139. BDA Industrial Suburb,
6th Main, Tumkur Road,
Peenya Post,
Bangalore, India – 560058
Tel.: +91-80-28078400
Email: vwr_india@vwr.com

Ireland / Northern Ireland

VWR International Ltd / VWR International
(Northern Ireland) Ltd
Orion Business Campus
Northwest Business Park
Ballycoolin
Dublin 15
Tel.: +353 01 88 22 222
Email sales.ie@vwr.com

Italy

VWR International S.r.l.
Via San Giusto 85
20153 Milano (MI)
Tel.: +39 02-3320311/02-487791
Email: info.it@vwr.com

Korea

VWR International ~
2F ACE Gwanggyo Tower I
Daehak 4ro 17
Yeongtong-gu Suwon
Korea 16226
Tel.: +82 31 645 7250
saleskorea@avantorsciences.com

Mexico

VWR International, S.de R.L. de C.V.
Km. 14.5 Carretera
Tlalnepantla-Cuautitlán
Col. Lechería
Tultitlán Edo. de México
CP 54940
Tel.: +52 (55) 5005 0100
vwrmx@vwr.com

Middle East & Africa

VWR International FZ-LLC
DSP Laboratory Complex
125, Floor 01
Dubai, United Arab Emirates
Tel.: +971 4 5573271
info.mea@vwr.com

The Netherlands

VWR International B.V.
Postbus 8198
1005 AD Amsterdam
Tel.: +31 020 4808 400
Email: info.nl@vwr.com

Norway

VWR International AS
Brynsalleen 4
0667 Oslo
Tel.: +47 22 90 00 00
Email: info.no@vwr.com

Poland

VWR International Sp. z o.o.
Limbowa 5
80-175 Gdansk
Tel.: +48 058 32 38 210
Email: info.pl@vwr.com

Portugal

VWR International - Material de
Laboratório, Lda
Centro Empresarial de Alfragide
Rua da Indústria, nº 6
2610-088 Amadora
Tel.: +351 21 3600 770
Email: info.pt@vwr.com

Singapore

VWR Singapore Pte Ltd
18 Gul Drive
Singapore 629468
Tel: +65 6505 0760
Email: sales.sg@vwr.com

Spain

VWR International Eurolab S.L.
C/ Tecnología 5-17
A-7 Llinars Park
08450 - Llinars del Vallès
Barcelona
Tel.: +34 902 222 897
Email: info.es@vwr.com

Sweden

VWR International AB
Fagerstagatan 18a
163 94 Stockholm
Tel.: +46 08 621 34 00
Email: info.se@vwr.com

Switzerland

VWR International GmbH
Lerzenstrasse 16/18
8953 Dietikon
Tel.: +41 044 745 13 13
Email: info.ch@vwr.com

UK

VWR International Ltd
Customer Service Centre
Hunter Boulevard
Magna Park
Lutterworth
Leicestershire
LE17 4XN
Tel.: +44 (0) 800 22 33 44
Email: uksales@vwr.com

United States

VWR International, LLC
100 Matsonford Road
Building One Suite 200
Radnor, PA 19087
Tel.: +1 800 932 5000
vwrcustomerService@vwr.com